DASH WARNING LIGHTS
PRINT OFF SHEET

Simple print off this page, cut out the image and place in the Glove Box

BRAKE WARNING LIGHT	SEAT BELT REMINDER LIGHT	OIL PRESSURE WARNING LIGHT	EXHAUST TEMP WARNING LIGHT	REAR WINDOW HEATER LIGHT	BATTERY WARNING LIGHT
This light will illuminate in the following conditions. *When the handbrake is pulled up. *When the brake fluid is low. **CAUTION! Top up your brake fluid ASAP.**	The light will illuminate when the ignition is "ON' and the drivers seat belt is not fastened and also a buzzer will sound for 6 seconds. When the drivers belt is fastened, the light will go out and the buzzer will stop. There is no alarm for passengers	This light illuminates when the oil pressure is low while the engine is running. **CAUTION! Stop the vehicle ASAP. Do not drive with this light on as it will damage the engine!**	This will illuminate when the Exhaust temperature abnormally hot. **CAUTION! If the light illuminates while driving slow down.**	This will illuminate when the Rear Window Heater switch has been activated.	This light indicates a fault related to the battery charging. Possibly a faulty Alternator. **CAUTION! Do not drive the car as it may stop suddenly.**

FIGARO DASH WARNING LIGHTS

Apply double sided tape and stick to inside of passenger sun blind

FIGARO
Owners Club